Pro Tools® | HD Native Pro Tools® 10 Pro Tools® HD-X Pro Tools® 11

Lynx Interface Guide



Avid Platfor	m	Lynx Interface	Notes
Pro Tools HE	O Native	Aurora 16HD Aurora 16-VTHD Aurora 8HD	This is 100% compatible with LT-HD equipped Aurora converters. While HD Native has a different feature set, its operation is similar to standard HD systems for Aurora converters. We have tested and verified this. HD Native handles up to 64 channels per card, so up to 4 Aurora converters can be used. Two Aurora 16-HD models in "32 channel mode" will use all 64 channels.
Pro Tools 9 a Software	& 10	AES16 Models ² AES16e Models ³ LynxTWO, L22 ² All Aurora Models Hilo	Pro Tools 9 and 10 are software only and will work with any Lynx interface. PCI audio card models AES16, LynxTWO and L22 are fully functional for up to 16 channels each. PCI-Express AES16e models are fully compatible and two can be used for 32 channels of I/O. Aurora converters using LT-USB in Mac and Windows platforms will also work. Compatible with Pro Tools Software via USB.
Pro Tools HE	DΧ	Aurora 16HD Aurora 16-VTHD Aurora 8HD	As with the Native card, HDX is 100% compatible with LT-HD equipped Aurora converters. ¹ HDX handles up to 64 channels per card, so up to 4 Aurora converters can be used. Two Aurora 16HD models in "32 channel mode" use all 64 channels.
Pro Tools 11		AES16e Models All Aurora Models Hilo	Initial tests show all compatibility as above. All interfaces fully functional Including interface via Thunderbolt chassis

¹ LT-HD version 10 firmware for LT-HD card allows Aurora converters to emulate Avid HD I/O connections and communcations

² Using the latest Lynx Windows 7 drivers.

³ Using either the Lynx Windows 7 or Apple drivers.